

SCRUBS® SCRUBS® MEDAPHENE® Plus Disinfecting Wipes

FEATURES

- One-step² disinfectant³/sanitizer⁴
 - ²On hard, non-porous, non-food surfaces
 - ³When used according to the disinfection directions
 - ⁴When used according to the sanitization directions
- Portable and easy to use
- No spraying or run-off

APPLICATIONS

- Bathtubs
- Toilet Seats
- Exterior Toilet Bowl Surfaces
- Sinks
- Faucet Handles
- Showers
- Glazed Tiles
- Chairs
- Computer Keyboards
- Desks
- Doorknobs
- Light Switches
- Telephones
- Walls
- Acrylic
- Formica®
- Glazed Porcelain
- Metal
- Finished Woodwork
- Stainless Steel
- Sealed Granite
- Plastic

DIRECTIONS

FOR USE: It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

FOR CLEANING/DEODORIZING: Wipe surface with wipe. Let air dry. Discard used wipe in trash. Do not flush in toilet.

FOR CLEANING AND DISINFECTION/VIRUCIDAL*/MOLD AND MILDEW CONTROL: Wipe hard, non-porous surface with wipe until surface is visibly wet. Use enough wipes to keep surfaces wet for 4 minutes. Allow surface to remain wet for 4 minutes. For Norwalk Virus and Rotavirus, treated surfaces must remain wet for 10 minutes. For SARS-CoV-2, treated surfaces must remain visibly wet for 15 seconds. Let air dry. If surfaces are visibly dirty, clean first with another wipe before disinfecting. Discard used wipe in trash. Do not flush in toilet.

FOR BACTERIOSTATIC USE: SCRUBS® MEDAPHENE® Plus Disinfecting Wipes will effectively inhibit the growth of odor-causing bacteria when applied to hard, non-porous surfaces. For visibly soiled surfaces, clean visible dirt first. Wipe surface and let it remain visibly wet for 4 minutes. Repeat treatment every 24 hours, or more often if new growth appears.

FOR MOLD AND MILDEW: SCRUBS MEDAPHENE PLUS DISINFECTING WIPES will effectively inhibit the growth of mold and mildew and the odors caused by them when applied to hard, non-porous surfaces. Follow disinfection instructions. Repeat treatment every seven days, or more often if new growth appears.

***KILLS HIV AND HBV PRE-CLEANED ENVIRONMENTAL SURFACES / OBJECTS PREVIOUSLY SOILED WITH BLOOD / BODY FLUIDS** in health care settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces / objects with blood or body fluids, and in which the surfaces / objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 or Hepatitis B Virus or Hepatitis C Virus.



PHYSICAL PROPERTIES

Appearance / Physical State	Wipes
Color	Colorless
Odor	Citrus
pH Value	11
Melting / Freezing Point	Not available.
Boiling Point / Range	212 °F (100 °C)
Flash Point	Not available.
Evaporation Rate	Not available
Flammability	Not available
Vapor Pressure	Not available
Vapor density	<1 (air=1)
Density	Not available
Partition Coefficient	Not available
Auto-Ignition Temperature	Not available
Water Solubility	Soluble
Specific Gravity	1.0
VOC Content	0.04%



CONTACT YOUR ITW PRO BRANDS REPRESENTATIVE TODAY!

800.241.8334 | www.itwprobrands.com

LPS®, SCRUBS®, DYKEM®, Accu-Lube®, DYMON®, Spray Nine®, and Cedar® are registered trademarks and Rustlick™, Diamondkote™, and MetalMates™ are trademarks of Illinois Tool Works • All Rights Reserved

SCRUBS® SCRUBS® MEDAPHENE® Plus Disinfecting Wipes

DIRECTIONS (CONTINUED)

Special Instructions for Cleaning and Decontamination against HIV-1 or HBV or HCV on Surfaces/ Objects Soiled With Blood/Body Fluids.

PERSONAL PROTECTION: Clean-up must always be done wearing protective gloves, gowns, masks and eye protection.

CLEANING PROCEDURE: Blood and other body fluids containing HIV or HBV or HCV must be visibly cleaned from surfaces and objects before application of SCRUBS® MEDAPHENE® Plus Disinfecting Wipes. This product can be used for this purpose.

CONTACT TIME: Leave surface visibly wet for 1 minute for HIV-1. Use appropriate contact time as listed on label for all other viruses and bacteria claimed.

DISPOSAL OF INFECTIOUS MATERIAL: Blood, body fluids, cleaning materials and clothing must be disposed of according to local regulations for infectious waste disposal.

SANITIZING: To sanitize hard, non-porous, non-food contact surfaces, wipe surface, using enough wipes to allow treated surface to remain visibly wet for 15 seconds for Staphylococcus aureus, Klebsiella pneumoniae, and Campylobacter jejuni. Let surface dry. For visibly soiled surfaces, clean visible soil first.

HANDLING

Avoid contact with eyes. Do not smoke. Handle in accordance with good industrial hygiene and safety practice.

STORAGE

Keep container closed when not in use. Keep container tightly closed in a dry and well-ventilated place. Keep away from heat and sources of ignition. Do not contaminate food or feed stuffs. Keep out of the reach of children.

DISPOSAL

Dispose of in accordance with local regulations. Do not re-use empty containers. Do not flush.

AVAILABLE PRODUCTS

Part No.	Net Contents	Container Type	Units/Case	Approximate Case Weight	Towel Size
96365	73 wipes	container	6	10 lbs	7 x 9 in
96390	90 wipes	container	6	10 lbs	7 x 8 in



CONTACT YOUR ITW PRO BRANDS REPRESENTATIVE TODAY!

800.241.8334 | www.itwprobrands.com

LPS®, SCRUBS®, DYKEM®, Accu-Lube®, DYMON®, Spray Nine®, and Cedar® are registered trademarks and Rustlick™, Diamondkote™, and MetalMates™ are trademarks of Illinois Tool Works • All Rights Reserved