Flood Coolant Accessories

DESCRIPTION

Quickly and accurately measures coolant concentration.

FEATURES

- Bright, easy-to-read scale
- Wide measurement range (0-32 Brix)
- Clear-view eyepiece
- No-slip handle
- Compatible with all coolant types and brands

APPLICATIONS

· Quickly and accurately measures coolant concentration.

DIRECTIONS

1. Place a few drops of diluted coolant on the prism and close the cover plate. 2. Hold refractometer horizontally and point the prism end toward a light source and focus the eyepiece until the scale is visible. 4. Read the scale value where the dark and light portions meet and record number. 5. Refer to Rustlick's Refractometer Index reader to determine concentration value.

HANDLING

Wear proper PPE when handling

STORAGE

Add Description Storage here

DISPOSAL INFORMATION

Add Description Disposal Info here



PROPERTIES

Appearance/physical state	
Odor	
Melting point/freezing point	
Boiling point/range	
Vapor pressure	
Partition coefficient	
Percent volatile	
Flammability limit	
Propellant	
VOC Content	
Color	
Flash point	
Relative density	
Evaporation rate	
Vapor density	
Auto-ignition temperature	
Viscosity	
Specific Gravity (water=1)	
Temperature Range °F(°C)	
4-Ball Weld Load	

SHELF LIFE INFORMATION

1 year

AVAILABLE PRODUCTS

Part No.	Net Contents	Container Type	Units/Case	Case Weight
78095	Refractometer	Size	0	00 lbs.

